




✓ Rust-resistant black oxide coating




✓ Alignment plug to keep the setup aligned with calibrating machine

✓ Adapters built to match specific button load cell dimensions



✓ Top adapter designed to eliminate misalignment and other measurement error



✓ Base block with inner diameter to accommodate the load cell

## Standard Features

- » Morehouse Button Load Cell Adapters have been designed to eliminate misalignment and other parasitic errors during calibration of button load cells.
- » Each set includes a base adapter, top alignment fixture, and an optional alignment plug for the base adapter.
- » Adapters help maintain the force application line aligned with the loading line of the load cell.
- » Counterbore in Top Alignment Fixture made to the specific button size on each load cell.
- » Improve calibration results by providing more repeatable measurements.
- » Lowers overall calibration time by facilitating easier and faster setup.
- » Rust-resistant black oxide coating on all adapters.



## List of Instruments to Calibrate

Instruments which can be calibrated with the adapters and corresponding part numbers

### Calibration Adapters Assembly Number Based on Button Load Cell Model

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
COOPER	LGP312-10	10	CPD-2100-1160	CP-2100	CD-1160
COOPER	LGP312-25	25	CPD-2100-1160	CP-2100	CD-1160
COOPER	LGP312-50	50	CPD-2110-1190	CP-2110	CD-1190
COOPER	LGP312-100	100	CPD-2110-1190	CP-2110	CD-1190
COOPER	LGP312-250	250	CPD-2110-1190	CP-2110	CD-1190
COOPER	LGP312-500	500	CPD-2110-1190	CP-2110	CD-1190
COOPER	LGP312-1K	1000	CPD-2110-1190	CP-2110	CD-1190
COOPER	LGP312-2K	2000	CPD-2120-1240	CP-2120	CD-1240
COOPER	LGP312-3K	3000	CPD-2120-1240	CP-2120	CD-1240
COOPER	LGP312-4K	4000	CPD-2120-1240	CP-2120	CD-1240
COOPER	LGP312-5K	5000	CPD-2120-1240	CP-2120	CD-1240
COOPER	LGP312-7.5K	7500	CPD-2130-1410	CP-2130	CD-1410
COOPER	LGP312-10K	10000	CPD-2130-1410	CP-2130	CD-1410
COOPER	LGP312-15K	15000	CPD-2130-1410	CP-2130	CD-1410
COOPER	LGP312-20K	20000	CPD-2130-1410	CP-2130	CD-1410
COOPER	LGP312-30K	30000	CPD-2130-1410	CP-2130	CD-1410
COOPER	LKCP410-25	25	CPD-1150-1120	CP-1150	CD-1120
COOPER	LKCP410-50	50	CPD-1150-1120	CP-1150	CD-1120
COOPER	LKCP410-100	100	CPD-1150-1120	CP-1150	CD-1120
COOPER	LKCP410-250	250	CPD-1180-1140	CP-1180	CD-1140
COOPER	LKCP410-500	500	CPD-1190-1140	CP-1190	CD-1140
COOPER	LKCP410-1K	1000	CPD-1190-1140	CP-1190	CD-1140
COOPER	LKCP410-2K	2000	CPD-1190-1140	CP-1190	CD-1140
COOPER	LKCP410-3K	3000	CPD-1210-1220	CP-1210	CD-1220
COOPER	LKCP410-4K	4000	CPD-1210-1220	CP-1210	CD-1220
COOPER	LKCP410-5K	5000	CPD-1210-1220	CP-1210	CD-1220
COOPER	LKCP410-7.5K	7500	CPD-1210-1220	CP-1210	CD-1220
COOPER	LKCP410-10K	10000	CPD-1210-1260	CP-1210	CD-1260
COOPER	LKCP410-15K	15000	CPD-1270-1270	CP-1270	CD-1270
COOPER	LKCP410-20K	20000	CPD-1270-1350	CP-1270	CD-1350



**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
COOPER	LPM510A-250g	0.55	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-500g	1.1	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-1000g	2.2	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-10	10	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-25	25	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-50	50	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510A-100	100	CPD-1110-1110	CP-1110	CD-1110
COOPER	LPM510A-250	250	CPD-1110-1110	CP-1110	CD-1110
COOPER	LPM510A-500	500	CPD-1130-1120	CP-1130	CD-1120
COOPER	LPM510A-1000	1000	CPD-1130-1120	CP-1130	CD-1120
COOPER	LPM510B-5	5	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510B-10	10	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510B-25	25	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510B-50	50	CPD-1100-1100	CP-1100	CD-1100
COOPER	LPM510B-100	100	CPD-1110-1110	CP-1110	CD-1110
COOPER	LPM510B-250	250	CPD-1110-1110	CP-1110	CD-1110
COOPER	LPM510B-500	500	CPD-1130-1120	CP-1130	CD-1120
COOPER	LPM510B-1K	1000	CPD-1130-1120	CP-1130	CD-1120
FUTEK	LLB210-10	10	CPD-1100-1100	CP-1100	CD-1100
FUTEK	LLB210-25	25	CPD-1100-1100	CP-1100	CD-1100
FUTEK	LLB210-50	50	CPD-1100-1100	CP-1100	CD-1100
FUTEK	LLB350-25	25	CPD-1150-1120	CP-1150	CD-1120
FUTEK	LLB350-50	50	CPD-1150-1120	CP-1150	CD-1120
FUTEK	LLB400-100	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB400-250	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB400-500	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB400-1K	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB400-2K	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB400-2.5K	2500	CPD-1180-1200	CP-1180	CD-1200
FUTEK	LLB450-5K	5000	CPD-1200-1260	CP-1200	CD-1260
FUTEK	LLB450-10K	10000	CPD-1200-1260	CP-1200	CD-1260
FUTEK	LLB500-15K	15000	CPD-1260-1350	CP-1260	CD-1350
FUTEK	LLB500-20K	20000	CPD-1260-1350	CP-1260	CD-1350
FUTEK	LLB550-50K	50000	CPD-2110-1355	CP-2110	CD-1355



**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
INTERFACE	LBM-25	25	CPD-1160-1120	CP-1160	CD-1120
INTERFACE	LBM-50	50	CPD-1160-1120	CP-1160	CD-1120
INTERFACE	LBM-100	100	CPD-1160-1120	CP-1160	CD-1120
INTERFACE	LBM-250	250	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBM-500	500	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBM-1K	1000	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBM-2K	2000	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBM-5K	5000	CPD-1210-1260	CP-1210	CD-1260
INTERFACE	LBM-10K	10000	CPD-1210-1260	CP-1210	CD-1260
INTERFACE	LBM-20K	20000	CPD-1270-1350	CP-1270	CD-1350
INTERFACE	LBMP-50N	11.2	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-100N	22.5	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-200N	45	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-500N	112	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-1kN	225	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-2kN	450	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-5kN	1120	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-10kN	2250	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMP-20kN	4500	CPD-1220-1220	CP-1220	CD-1220
INTERFACE	LBMP-50kN	11200	CPD-1280-1270	CP-1280	CD-1270
INTERFACE	LBMP-100kN	22500	CPD-1370-1360	CP-1370	CD-1360
INTERFACE	LBMU-100	100	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-250	250	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-500	500	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-1K	1000	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-450kN	100	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-1.1kN	250	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-2.2kN	500	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	LBMU-4.45kN	1000	CPD-1190-1140	CP-1190	CD-1140
INTERFACE	MSC-15K	15000	CPD-1190-1370	CP-1190	CD-1370
INTERFACE	MSC-20K	20000	CPD-1190-1370	CP-1190	CD-1370
INTERFACE	MSC-30K	30000	CPD-1190-1370	CP-1190	CD-1370
INTERFACE	MSC-65kN	15000	CPD-1190-1370	CP-1190	CD-1370
INTERFACE	MSC-90kN	20000	CPD-1190-1370	CP-1190	CD-1370
INTERFACE	MSC -30kN	30000	CPD-1190-1370	CP-1190	CD-1370



**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
OMEGA	LC302-25	25	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC302-50	50	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC302-100	100	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC302-250	250	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC302-500	500	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC302-1K	1000	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-100N	22.5	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-200N	45	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-500N	112	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-1kN	225	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-2kN	450	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LCM302-5kN	1120	CPD-1130-1120	CP-1130	CD-1120
OMEGA	LC304-100	100	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-500	500	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-1K	1000	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-3K	3000	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-5K	5000	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-7.5K	7500	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LC304-10K	10000	CPD-1160-1250	CP-1160	CD-1250
OMEGA	LCM304-500N	112	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LCM304-5kN	1120	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LCM304-10kN	2250	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LCM304-20kN	4500	CPD-1160-1210	CP-1160	CD-1210
OMEGA	LCM304-50kN	11200	CPD-1160-1250	CP-1160	CD-1250
OMEGA	LC305-25	25	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-50	50	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-100	100	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-200	200	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-300	300	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-500	500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-1K	1000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-2K	2000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-2.5K	2500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-5K	5000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC305-8K	8000	CPD-1270-1220	CP-1270	CD-1220



**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
OMEGA	LC305-10K	10000	CPD-1270-1260	CP-1270	CD-1260
OMEGA	LCM305-100N	22.5	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-200N	45	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-500N	112	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-1kN	225	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-2kN	450	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-10kN	2250	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-20kN	4500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM305-50kN	11200	CPD-1270-1260	CP-1270	CD-1260
OMEGA	LC307-250	250	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LC307-500	500	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LC307-1K	1000	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LC307-2K	2000	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LC307-3K	3000	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LC307-5K	5000	CPD-1120-1230	CP-1120	CD-1230
OMEGA	LC307-7.5K	7500	CPD-1140-1280	CP-1140	CD-1280
OMEGA	LC307-10K	10000	CPD-1140-1280	CP-1140	CD-1280
OMEGA	LCM307-1kN	225	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LCM307-2kN	450	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LCM307-5kN	1120	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LCM307-10kN	2250	CPD-1110-1170	CP-1110	CD-1170
OMEGA	LCM307-20kN	4500	CPD-1120-1230	CP-1120	CD-1230
OMEGA	LCM307-50kN	11200	CPD-1140-1280	CP-1140	CD-1280
OMEGA	LC315-25	25	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-50	50	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-100	100	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-200	200	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-300	300	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-500	500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-1K	1000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-2K	2000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-2.5K	2500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-5K	5000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-8K	8000	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LC315-10K	10000	CPD-1270-1260	CP-1270	CD-1260



**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
OMEGA	LCM315-100N	22.5	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-200N	45	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-500N	112	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-1kN	225	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-2kN	450	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-10kN	2250	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-20kN	4500	CPD-1270-1220	CP-1270	CD-1220
OMEGA	LCM315-50kN	11200	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBC-100	100	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-100A	100	CPD-1160-1120	CP-1160	CD-1120
TRANSDUCER TECHNIQUES	LBC-250	250	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-500	500	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-750	750	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-1K	1000	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-2K	2000	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBC-3K	3000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBC-5K	5000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBC-10K	10000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBC-15K	15000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	LBC-20K	20000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	LBC-30K	30000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	LBM-50	50	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-100	100	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-200	200	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-500	500	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-1K	1000	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-2K	2000	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-2.5K	2500	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-5K	5000	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-8K	8000	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBM-10K	10000	CPD-1270-1260	CP-1270	CD-1260
TRANSDUCER TECHNIQUES	LBO-100	100	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBO-100A	100	CPD-1160-1120	CP-1160	CD-1120
TRANSDUCER TECHNIQUES	LBO-250	250	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBO-500	500	CPD-1180-1140	CP-1180	CD-1140





**Calibration Adapters Assembly Number Based on Button Load Cell Model**

Manufacturer	Instrument Model No.	Capacity (lbf)	Adapter Assembly	Base Part No.	Ball Alignment Part No.
TRANSDUCER TECHNIQUES	LBO-750	750	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBO-1K	1000	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBO-2K	2000	CPD-1180-1140	CP-1180	CD-1140
TRANSDUCER TECHNIQUES	LBO-3K	3000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBO-5K	5000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBO-10K	10000	CPD-1200-1265	CP-1200	CD-1265
TRANSDUCER TECHNIQUES	LBO-15K	15000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	LBO-20K	20000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	LBO-30K	30000	CPD-1260-1350	CP-1260	CD-1350
TRANSDUCER TECHNIQUES	MLC-2K	2000	CPD-1118-1265	CP-1118	CD-1265
TRANSDUCER TECHNIQUES	MLC-3K	3000	CPD-1118-1265	CP-1118	CD-1265
TRANSDUCER TECHNIQUES	MLC-5K	5000	CPD-1118-1265	CP-1118	CD-1265
TRANSDUCER TECHNIQUES	MLC-7.5K	7500	CPD-1138-1352	CP-1138	CD-1352
TRANSDUCER TECHNIQUES	MLC-10K	10000	CPD-1138-1352	CP-1138	CD-1352
TRANSDUCER TECHNIQUES	MLC-15K	15000	CPD-1191-1365	CP-1191	CD-1365
TRANSDUCER TECHNIQUES	MLC-20K	20000	CPD-1191-1365	CP-1191	CD-1365
TRANSDUCER TECHNIQUES	MLC-30K	30000	CPD-1191-1365	CP-1191	CD-1365
TRANSDUCER TECHNIQUES	SLB-25	25	CPD-1100-1100	CP-1100	CD-1100
TRANSDUCER TECHNIQUES	SLB-50	50	CPD-1100-1100	CP-1100	CD-1100
TRANSDUCER TECHNIQUES	SLB-100	100	CPD-1110-1110	CP-1110	CD-1110
TRANSDUCER TECHNIQUES	SLB-250	250	CPD-1110-1110	CP-1110	CD-1110
TRANSDUCER TECHNIQUES	SLB-500	500	CPD-1130-1120	CP-1130	CD-1120
TRANSDUCER TECHNIQUES	SLB-750	750	CPD-1130-1120	CP-1130	CD-1120
TRANSDUCER TECHNIQUES	SLB-1K	1000	CPD-1130-1120	CP-1130	CD-1120
TRANSDUCER TECHNIQUES	SSM-50	50	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-100	100	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-200	200	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-500	500	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-1K	1000	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-2K	2000	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-2.5K	2500	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-5K	5000	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-8K	8000	CPD-1270-1225	CP-1270	CD-1225
TRANSDUCER TECHNIQUES	SSM-10K	10000	CPD-1270-1267	CP-1270	CD-1267